



NO	HHAW PARTS NO		Q' TY/UNIT	PARTS NAME
	RAC-35WPB			
1	HWRAC-35WPB	A01	1	BASE
2	HWRAC-18WEB	A02	1	COMPRESSOR
3	HWRAC-25YH4	A04	3	PUSH NUT
4	HWRAC-35WPB	A02	1	CONDENSER
5	HWRAC-35WPB	A03	1	REVERSING VALVE
6	HWRAC-50WEA	A06	1	2S-VALVE
7	HWRAC-10GH5	A03	1	3S-VALVE
8	HWRAC-SX10HAK	A09	1	SOUND PROOF COVER ASSEMBLY
9	HWRAC-35YH4	A03	1	ELECTRIC EXPANSION VALVE
10	HWRAC-SX10HAK	A10	1	SOUND PROOF COVER ASSEMBLY
11	HWRAC-18WEB	A07	1	O. L. R COVER
12	HWRAC-25WXA	A04	1	SOUND PROOF COVER ASSEMBLY
13	HWRAC-18WSA	A11	1	CONNECTING CORD (COMP)
14	HWRAC-25WXA	A05	1	THERMISTOR (DEFROST)
15	HWRAC-25WX8	A02	1	THERMISTOR SUPPORT
16	HWRAC-SX10HAK	A20	1	COIL (REVERSING VALVE)
17	HWRAC-35YHA4	A04	1	COIL (EXPANSION VALVE)
18	HWRAC-35WPB	A04	1	PARTITION
19	HWRAC-18WEB	A10	1	REACTOR 1
20	HWRAC-35WPB	A05	1	SOUND PROOF COVER ASS' Y
21	HWRAC-14EH4	A08	1	FAN MOTOR SUPPORT
22	HWRAC-18WEB	A12	1	FAN MOTOR
23	HWRAC-14EH4	A09	1	PROPELLER FAN
24	HWRAC-25YH4	A24	1	NUT (PROPELLER. FAN)
25	HWRAC-25YH4	A25	1	SIDE COVER (L)
26	HWRAC-25YH4	A26	1	HANDLE
27	HWRAC-35WPB	A06	1	FRONT COVER
28	HWRAC-E14H3	909	1	DISCHARGE GRILL
29	HWRAC-35WPB	A07	1	ELECTRIC PARTS PLATE
30	HWRAC-35WPB	A08	1	ELECTRIC PARTS COVER
31	HWRAC-25YH4	A50	1	DRAIN PIPE
32	HWRAC-18WEB	A19	1	TERMINAL BOARD (5P)
33	HWRAC-35WPB	A09	1	HEAT SINK (REGURATOR 1)
34	HWRAC-35WPB	A10	1	P. W. B. (POWER)
35	HWRAC-35WPB	A11	1	SUPPORT (P. W. B.)
36	HWRAC-18WEB	A22	1	FUSE (15A)
37	HWRAC-14EH4	A15	1	COVER (OUT DOOR THERMISTOR)
38	HWRAC-E14H3	914	1	THERMISTOR (OUTDOOR TEMPERATURE)
39	HWRAC-E14H3	915	1	SIDE COVER (R)
40	HWRAC-35WPB	A12	1	TERMINAL COVER
41	HWRAC-25WXA	A09	1	TOP COVER
42	HWRAC-25YH4	A47	1	SERVICE VALVE COVER
43	HWRAC-25YH4	A48	1	BUSH ASSEMBLY
44	HWRAC-25YH4	A49	1	BUSH
45	HWRAC-SX10HAK	A11	1	SOUND PROOF COVER ASS' Y
46	HWRAC-SX10HAK	A12	1	SOUND PROOF COVER ASS' Y
47	HWRAC-35WPB	A13	1	SOUND PROOF COVER ASS' Y
48	HWRAC-18WEB	A03	3	COMPRESSOR RUBBER
49	HWRAC-E08H	A11	1	FUSE (15A)
50	HWRAC-50NX2	A52	2	FUSE (3. 15A)