



| NO | PARTS No.        | Q'TY | PARTS NAME                 |
|----|------------------|------|----------------------------|
|    | RAC-35YH6        |      |                            |
| 1  | HWRAC-E14H2 A01  | 1    | BASE                       |
| 2  | HWRAC-E08H A02   | 1    | COMPRESSOR 750W 8.0kg      |
| 3  | HWRAC-25YH4 A03  | 3    | COMPRESSOR RUBBER          |
| 4  | HWRAC-25YH4 A04  | 3    | PUSH NUT                   |
| 5  | HWRAC-D10EX2 A02 | 1    | CONDENSER                  |
| 6  | HWRAC-E08H A03   | 1    | REVERSING VALVE            |
| 7  | HWRAC-E08H A04   | 1    | SERVICE VALVE ASS'Y        |
| 8  | HWRAC-E08H A05   | 1    | ELECTRIC EXPAN. VALVE      |
| 9  | HWRAC-E08H A06   | 1    | SOUND PROOF COVER ASS'Y    |
| 10 | HWRAC-25YH4 A10  | 1    | O.L.R COVER                |
| 11 | HWRAC-25YH4 A11  | 1    | O.H THERMI. SUPPORT        |
| 12 | HWRAC-25YHA1 A01 | 1    | CONNECTING CORD(COMP)      |
| 13 | HWRAC-D10EX A08  | 1    | THERMISTOR(DEFROST)        |
| 14 | HWRAC-25YH4 A14  | 1    | THERMISTOR SUPPORT         |
| 15 | HWRAC-25YHA A03  | 1    | COIL(REVERS.VALVE)         |
| 16 | HWRAC-E08H A09   | 1    | COIL(EXPAN.VALVE)          |
| 17 | HWRAC-25YH4 A17  | 1    | PARTITION                  |
| 18 | HWRAC-25YH4 A18  | 1    | REACTOR COVER              |
| 19 | HWRAC-25YH4 A02  | 1    | REACTOR1                   |
| 20 | HWRAC-25YH4 A03  | 1    | REACTOR2                   |
| 21 | HWRAC-D10EX A11  | 1    | FAN MOTOR SUPPORT          |
| 22 | HWRAC-25YH4 A22  | 1    | FAN MOTOR 40W 1.5kg        |
| 23 | HWRAC-25YH4 A23  | 1    | PROPELLER FAN              |
| 24 | HWRAC-25YH4 A24  | 1    | NUT(PROPELLER.FAN)         |
| 25 | HWRAC-25YH4 A25  | 1    | SIDE COVER(L)              |
| 26 | HWRAC-25YH4 A26  | 1    | HANDLE                     |
| 27 | HWRAC-E08H A10   | 1    | FRONT COVER                |
| 28 | HWRAC-25YH4 A28  | 1    | DISCHARGE GRILL            |
| 29 | HWRAC-25YH4 A29  | 1    | ELECTRIC PARTS PLATE       |
| 30 | HWRAC-E08H A15   | 1    | ELECTRIC PARTS COVER       |
| 31 | HWRAC-25YH4 A31  | 1    | TERMINAL PLATE             |
| 32 | HWRAC-25YH4 A32  | 2    | TERMINAL BOARD(2P)         |
| 33 | HWRAC-25YH4 A33  | 1    | HEAT SINK(REGURATOR1)      |
| 34 | HWRAC-25YH5 A01  | 1    | P.W.B.(POWER)              |
| 35 | HWRAC-E08H A11   | 1    | FUSE(15A)                  |
| 36 | HWRAC-25YH4 A36  | 1    | FUSE(3A)                   |
| 37 | HWRAC-25YH4 A37  | 3    | VARISTOR                   |
| 38 | HWRAC-E14H2 A02  | 1    | P.W.B.(MAIN)               |
| 39 | HWRAC-25YH4 A39  | 1    | FUSE(1A)                   |
| 40 | HWRAC-25YH4 A40  | 2    | SUPPORT(P.W.B.)            |
| 41 | HWRAC-25YH4 A41  | 1    | CAPACITOR 45 $\mu$ F 200V  |
| 42 | HWRAC-25YH4 A42  | 1    | COVER(OUT DOOR THERMISTOR) |
| 43 | HWRAC-D10EX A17  | 1    | THERMISTOR(OUT DOOR TEMP.) |
| 44 | HWRAC-E14H2 A03  | 1    | SIDE COVER(R)              |
| 45 | HWRAC-25YH4 A45  | 1    | TERMINAL COVER             |
| 46 | HWRAC-25YH4 A46  | 1    | TOP COVER                  |
| 47 | HWRAC-25YH4 A47  | 1    | SERVICE VALVE COVER        |
| 48 | HWRAC-25YH4 A48  | 1    | BUSH ASS'Y                 |
| 49 | HWRAC-25YH4 A49  | 1    | BUSH                       |
| 50 | HWRAC-25YH4 A50  | 1    | DRAIN PIPE                 |
| 51 | HWRAC-25YH4 A51  | 1    | COVER(CAPACITOR)           |
| 52 | HWRAC-25YH4 A52  | 1    | CORD ASS'Y                 |