



| NO | HHAW PARTS NO | Q' TY/UN IT | PARTS NAME |
|----|-----------------|----------------|-------------------------|
| 1 | HWRAS-25WX8 A01 | 1 | CABINET |
| 2 | HWRAS-25WX8 A02 | 1 | FAN MOTOR |
| 3 | HWRAS-25WX8 A03 | 1 | TANGENTIAL AIR FLOW FAN |
| 4 | HWRAS-25WX8 A04 | 1 | FAN SUPPORT ASSMBLY |
| 5 | HWRAS-25WX8 A05 | 1 | FAN COVER |
| 6 | HWRAS-25WX8 A06 | 1 | FAN MOTOR SUPPORT |
| 7 | HWRAS-25WX8 A07 | 1 | CYCLE ASSEMBLY |
| 8 | HWRAS-25WX8 A08 | 1 | UPPER COVER |
| 9 | HWRAS-25WX8 A09 | 1 | SPRING |
| 10 | HWRAS-25WX8 A10 | 1 | TERMINAL BOARD (2P) |
| 11 | HWRAS-25WX8 A12 | 1 | THERMISTOR ASSEMBLY |
| 12 | HWRAS-25WX8 A01 | 1 | P. W. B. (MAIN) |
| | HWRAS-25WX8 A02 | 1 | |
| 13 | HWRAS-25WX8 A03 | 1 | P. W. B. (RECEIVER) |
| 14 | HWRAS-25WX8 A04 | 1 | DRAIN PAN ASSEMBLY |
| 15 | HWRAS-25WX8 A17 | 1 | AUTO SWEEP MOTOR-1 |
| 16 | HWRAS-25WX8 A18 | 1 | AUTO SWEEP MOTOR-2 |
| 17 | HWRAS-25WX8 A19 | 1 | FRONT COVER ASSEMBLY |
| 18 | HWRAS-25WX8 A20 | 1 | FRONT PANEL ASSEMBLY |
| 19 | HWRAS-25WX8 A22 | 1 | AIR FILTER (RIGHT) |
| 20 | HWRAS-25WX8 A23 | 1 | AIR FILTER (LEFT) |
| 21 | HWRAS-25WX8 A24 | 1 | LOWER COVER (RIGHT) |
| 22 | HWRAS-25WX8 A25 | 1 | LOWER COVER (LEFT) |
| 23 | HWRAS-25WX8 A26 | 1 | MOUNTING PLATE |
| 24 | HWRAS-25WX8 A05 | 1 | REMOTE CONTROL SUPPORT |
| 25 | HWRAS-25WX8 A06 | 1 | REMOTE CONTROL ASSEMBLY |
| 26 | HWRAS-25WX8 A29 | 1 | GEAR ASSEMBLY |
| 27 | HWRAS-25WX8 A30 | 1 | AUTO SWEEP MOTOR (GEAR) |
| 28 | HWRAS-25WX8 A31 | 1 | LIMIT SWITCH |
| 29 | HWRAS-25WX8 A32 | 1 | IONIZER UNIT |
| 30 | HWRAS-25WX8 A33 | 1 | IONIZER CASING |
| 31 | HWRAS-25WX8 A34 | 1 | THERMISTOR SUPPORT |
| 32 | HWRAS-25WX8 A35 | 2 | SCREW CAP |
| 33 | HWRAS-25WX8 A36 | 1 | T-COVER |