

MODEL: RAS-3HVNC1

(P0147x-03)

NO.	PART NAME	REPLACEMENT PART		Q'TY PER UNIT	SUMMARY	UNIT VOLTAGE CATEGORY										CATEGORY CODE	VOLTAGE (V)	FREQUENCY(HZ)	PHASES
		DRAW. NO.	ORDER NO.			V													
U01A	PRESSURE SW	17C83435A	P26839	1	HIGH PRESSURE	V													
U01B	PRESSURE SW	17C90587A	P27469	1	FOR CONTROL	V													
U04	FUSE	17A19127A	P27478	3	3A	V									V	220/240	50	1	
U15A	THERMISTOR	17C59663E	P23505	1	TA	V													
U15B	THERMISTOR	17C59664D	P23504	1	TE	V													
U15C	THERMISTOR	17C90955A	P27474	1	TD	V													
U21A	EXP. VALVE	17A19756A	P27689	1		V													
U21B	COIL FOR EXP. VALVE	17A19754A	P27690	1		V													
U27A	STOP VALVE	17C93039A	P27691	1	GAS LINE	V													
U27B	STOP VALVE	17C87971A	P27030	1	LIQUID LINE	V													
U28	CHECK JOINT	17C75461B	P25933	1		V													
U32A	VIBRATION ABSORBER	17G89712A	P27461	3		V													
U32B	VIBRATION ABSORBER	17G89713A	P27463	1		V													
U34A	AIR GRILLE	17A19842A	P27734	1	OUTLET	V													
U34B	AIR GRILLE	17A18972A	P27451	1	INLET	V													
U40	CONDENSER ASSEMBLY	17B38804B	P28995	1		V													
U48	ELECTRICAL BOX ASS'Y	17H12854P	P29993	1		V													
U51	PROPELLER FAN	17H16813A	P27454	1		V													
U70	COMPRESSOR	17F07817C	P28914	1		V													
U71	MOTOR	17A23294A	P29515	1		V													
U78	OIL HEATER	17A19294A	P27556	1		V													
U79	FOUR-WAY VALVE ASS'Y	17C76061A	P26440	1		V													
U81	COIL FOR 4-WAY VALVE	17C74970A	P26678	1		V													
U82	REACTOR	17A18986A	P27482	1		V													
U85	PRINTED CIRCUIT BOARD	17G64408B	P27839	1		V													
U89	ACCUMULATOR	17F08276A	P29111	1		V													
U98A	CABINET PANEL	17A18973B	P27656	1		V													
U98B	CABINET PANEL	17B38685B	P27657	1		V													
U98C	CABINET PANEL	17A18978A	P27448	1		V													
U98D	CABINET PANEL	17C91216A	P27449	1		V													
U98E	CABINET PANEL	17A21936A	P28607	1		V													
U100	SPECIAL NUT	17B38717A	P27456	1	for Propeller Fan	V													
U101	BOTTOM BASE ASSY	17B44736A	P29766	1		V													

Notes:
 1. Refer to page D-RAS-3HVNC1-V for the location of the listed parts.
 2. The replacement part drawing number marked ""*"" is different from that of the unit part.
 Change the setting for this unit, if required.

