



NO.	PART NO.		Q'TY / UNIT	PARTS NAME
1	KPNT1	001	4	PUSH NUT
2	RAC-2226HV	805	3	COMPRESSOR RUBBER
3	PMRAC-25NH4	S09	1	OVERHEAT THERMISTOR SUPPORT
4	PMRAC-25NPA	S02	1	ELECTRICAL EXPANSION COIL
5	PMRAC-25NPA	S03	1	EXPANSION VALVE
6	PMRAC-30MH1	S05	1	TOP COVER
7	PMRAC-50NH4	S03	1	VALVE (2S)
8	PMRAC-50NH4	S04	1	VALVE (4S)
9	PMRAC-50NPD	S01	1	COMPRESSOR
10	PMRAC-50NPD	S02	1	P.W.B (MAIN)
11	PMRAC-50NPD	S03	1	CONDENSOR
12	PMRAC-50NPD	S04	1	STRAINER (COND)
13	PMRAC-50NPD	S05	1	CABINET
14	PMRAC-50NPD	S06	1	STRAINER (PIPE)
15	PMRAC-50YHA2	S04	1	REACTOR
16	PMRAC-50YHA2	S08	1	THERMISTOR (OUTSIDE TEMPERATURE)
17	PMRAC-50YHA4	S02	1	IPM BOARD
18	PMRAC-50YHA4	S03	1	CAPACITOR BOARD
19	PMRAC-50YHA4	S04	1	TERMINAL BOARD (5P)
20	PMRAC-50NPD	S07	1	D-GRILL
21	PMRAC-60YHA4	S03	1	SIDE PLATE R
22	PMRAC-60YHA4	S04	1	SV-COVER-ASSY
23	PMRAC-70YHA	S07	1	PROPELLER FAN
24	PMRAC-80YHA	S14	1	THERMISTOR (OH)
25	PMRAC-S18CPA	S02	1	REVERSING VALVE
26	PMRAC-X13CX	906	1	OVERLOAD RELAY COVER
27	PMRAM-53NP2B	S10	1	FAN MOTOR
28	PMRAM-65QHA4	S12	1	THERMISTOR (DEFROST)
29	PMRAM-72Q9	S05	1	SIDE PLATE L
30	PMRAM-72Q9	S08	1	SUPPORT (FAN MOTOR)
31	PMRAM-90NP5B	S09	1	MG-COIL (REVERSING VALVE)