



NQ.	PART NO.	Q'TY/ UNIT	PARTS NAME
2	PMRAM-53NP2A S01	1	COMPRESSOR
3	KPNT1 001	3	PUSH NUT
4	RAC-2226HV 805	3	COMPRESSOR RUBBER
5	PMRAC-50NH4 S02	1	CONDENSER
6	PMRAC-X24CAT S02	1	REVERSING VALVE
7	PMRAM-72QH5 907	1	EXPANSION VALVE COIL (W)
8	PMRAM-72QH5 S06	1	EXPANSION VALVE COIL (R)
9	PMRAM-72QH5 S05	1	EXPANSION VALVE COIL (B)
10	PMRAM-65QH4 S15	3	VALVE (2S)
11	PMRAM-65QH4 S16	3	VALVE (3S)
12	PMRAC-40CNH2 S14	1	THERMISTOR (OH)
13	PMRAC-25NH4 S09	1	THERMISTOR SUPPORT (OH)
16	PMRAC-60YHA1 902	1	MG-COIL (REVERSING VALVE)
18	PMRAM-65QH4 S10	1	THERMISTOR (OUTSIDE TEMPERATURE)
19	PMRAC-70YHA 907	1	PROPELLER FAN
20	PMRAC-40CNH2 S18	1	SUPPORT (FAN MOTOR)
21	PMRAC-40CNH2 S19	1	FAN MOTOR
22	PMRAM-52QH5 S02	1	CABINET
23	PMRAC-24CP5 904	1	NET
24	PMRAC-40CNH2 922	1	TOP COVER
25	PMRAM-65QH4 S11	1	SIDE PLATE R
26	PMRAC-40CNH2 926	1	SIDE PLATE L
27	PMRAM-52QH5 S03	1	D-GRILL-AS
29	PMRAM-65QH4 S03	3	ELECTRICAL EXPANSION VALVE
30	PMRAM-65QH4 917	1	STRAINER (ST-PIPE-AS 1)
31	PMRAM-65QH4 918	1	STRAINER (ST-PIPE-AS 2)
32	PMRAM-65QH4 919	1	STRAINER (ST-PIPE-AS 3)
33	PMRAM-65QH4 920	1	STRAINER (CO-PIPE-AS 1)
34	PMRAC-07CV1 R06	1	2P TERMINAL
35	PMRAC-53NP3A S01	1	P.W.B. (MAIN)
	PMRAM-53NP3A S91	1	P.W.B. (MAIN) TUFFY
36	PMRAC-53NP3A S02	1	PWB (POWER)
37	PMRAC-40CNH2 S08	1	REACTOR
38	PMRAM-65QH4 921	1	SV-COVER
39	PMRAM-53NP2A S04	1	SYSTEM POWER MODULE
40	PMRAM-65QH4 S12	1	THERMISTOR (DEFROST)
41	PMRAM-65QH4 S07	1	THERMISTOR SUPPORT
42	PMRAM-65QH4 S13	1	THERMISTOR-V (W)
43	PMRAM-65QH4 S14	1	THERMISTOR-V (R)