



NO.	PART NO.	Q'TY / UNIT	PARTS NAME
1	PMRAC-07CV1 R06	2	2P TERMINAL
2	PMRAM-90QH5 901	5	2P TERMINAL
3	PMRAM-90NP5A S02	1	CABINET
4	RAC-2226HV 805	3	COMPRESSOR RUBBER
5	PMRAM-90QH5 903	1	COMPRESSOR
6	PMRAM-90QH5 904	1	CONDENSER
7	PMRAM-90QH5 905	1	D-GRILL
8	PMRAM-65QH4 S06	1	EXPANSION VALVE COIL (B)
9	PMRAM-65QH4 S05	1	EXPANSION VALVE COIL (R)
10	PMRAM-65QH4 S04	1	EXPANSION VALVE COIL (W)
11	PMRAM-90QH5 S06	1	EXPANSION VALVE COIL (BLK)
12	PMRAM-90QH5 908	1	FAN MOTOR
13	PMRAC-60YHA1 902	1	MG-COIL (REVERSING VALVE)
14	PMRAC-70YHA S06	1	NET
15	PMRAC-25NH4 910	1	OLR COVER
16	PMRAM-90NP5A S01	1	P.W.B (MAIN)
17	PMRAM-90NP5A S03	1	PROPELLER FAN
18	KPNT1 001	3	PUSH NUT
19	PMRAM-90QH5 911	1	PWB (POWER)
20	PMRAM-90QH5 912	1	REACTOR
21	PMRAC-X24CAT S02	1	REVERSING VALVE
22	PMRAM-90QH5 913	1	PLATE
23	PMRAM-90QH5 914	1	SIDE PLATE R
24	PMRAM-90QH5 915	1	STRAINER (CO-PIPE-AS 1)
25	PMRAM-90QH5 916	1	STRAINER (ST-PIPE-AS)
26	PMRAM-90QH5 917	1	3S PIPE-AS
27	PMRAM-90QH5 918	1	5S PIPE-AS
28	PMRAM-90QH5 907	1	EXPANSION VALVE COIL Y
29	PMRAM-90QH5 919	1	SUPPORT (FAN MOTOR)
30	PMRAM-90QH5 920	1	FAN MOTOR BRACKET
31	PMRAM-90QH5 921	1	SYSTEM POWER MODULE
32	PMRAM-90QH5 922	1	THERMISTOR (DEFROST)

NO.	PART NO. RAM-90NP5A	Q'TY / UNIT	PARTS NAME
33	PMRAC-80YHA S14	1	THERMISTOR (OH)
34	PMRAM-90QH5 923	1	THERMISTOR (OUTSIDE TEMPERATURE)
35	PMRAM-90QH5 924	1	THERMISTOR-PIPE (W)
36	PMRAM-90QH5 925	1	THERMISTOR-PIPE (N)
37	PMRAM-90QH5 926	1	TOP COVER
38	PMRAM-90QH5 927	1	VALVE (3S)
39	PMRAM-90QH5 928	1	VALVE (5S)
41	PMRAM-90QH5 929	5	EXPANSION VALVE
42	PMRAM-90QH5 930	1	PWB (CAPA)
43	PMRAM-65QH4 S07	1	SUPPORT (DEF-THERMISTOR)
44	PMRAC-25NH4 909	1	SUPPORT (OH-THERMISTOR)
45	PMRAM-90QH5 932	1	BACKPLATE
46	PMRAM-90QH5 S36	1	FRONTPLATE
48	PMRAC-18CVP2 S01	1	2P TERMINAL
49	PMRAM-90QH5 931	1	IPM-BOARD
50	PMRAM-90QH5 S33	5	2 UNION
51	PMRAM-90QH5 S34	3	3 UNION
52	PMRAM-90QH5 S35	2	4 UNION