

NO.	PART NO.		Q'TY / UNIT	PARTS NAME
2	PMRAC-VX13CET	S04	5	3P TERMINAL
3	PMRAM-90NP5A	S02	1	CABINET
4	RAC-2226HV	805	3	COMPRESSOR RUBBER
5	PMRAM-90NP5B	S15	1	COMPRESSOR
6	PMRAM-90QH5	904	1	CONDENSER
7	PMRAM-90QH5	905	1	D-GRILL
8	PMRAM-90NP5B	S05	1	EXPANSION VALVE COIL (B)
9	PMRAM-90NP5B	S04	1	EXPANSION VALVE COIL (R)
10	PMRAM-90NP5B	S03	1	EXPANSION VALVE COIL (W)
11	PMRAM-90NP5B	S06	1	EXPANSION VALVE COIL (BLK)
12	PMRAM-90NP5B	S08	1	FAN MOTOR
13	PMRAM-90NP5B	S09	1	MG-COIL (REVERSING VALVE)
14	PMRAC-70YHA	S06	1	NET
15	PMRAC-X13CX	910	1	OVERLOAD RELAY COVER
16	PMRAM-90NP5B	S02	1	P.W.B (INVERTER)
17	PMRAM-90NP5A	S03	1	PROPELLER FAN
18	KPNT1	001	3	PUSH NUT
19	PMRAM-90NP5B	S01	1	PWB (MAIN)
20	PMRAC-X18CD	S04	1	REACTOR
21	PMRAC-X24CAT	S02	1	REVERSING VALVE
22	PMRAM-90QH5	913	1	PLATE
23	PMRAM-90QH5	914	1	SIDE PLATE R
24	PMRAM-90QH5	915	1	STRAINER (CO-PIPE-AS 1)
25	PMRAM-90QH5	916	1	STRAINER (ST-PIPE-AS)
26	PMRAM-90QH5	917	1	3S PIPE-AS
27	PMRAM-90QH5	918	1	5S PIPE-AS
28	PMRAM-90QH5	907	1	EXPANSION VALVE COIL Y
29	PMRAM-90QH5	919	1	SUPPORT (FAN MOTOR)
30	PMRAM-90QH5	920	1	FAN MOTOR BRACKET
32	PMRAM-90NP5B	S10	1	THERMISTOR (DEFROST)

NO.	PART NO. RAM-90NP5B		Q'TY / UNIT	PARTS NAME
33	PMRAC-80YHA	914	1	THERMISTOR (OH)
34	PMRAM-90NP5B	S11	1	THERMISTOR (OUTSIDE TEMPERATURE)
35	PMRAM-90NP5B	S12	1	THERMISTOR-PIPE (W)
36	PMRAM-90NP5B	S13	1	THERMISTOR-PIPE (N)
37	PMRAM-90QH5	926	1	TOP COVER
38	PMRAM-90QH5	927	1	VALVE (3S)
39	PMRAM-90QH5	928	1	VALVE (5S)
41	PMRAM-90NP5B	S14	5	EXPANSION VALVE
43	PMRAM-65QH4	S07	1	SUPPORT (DEF-THERMISTOR)
44	PMRAC-25NH4	909	1	SUPPORT (OH-THERMISTOR)
45	PMRAM-90QH5	932	1	BACKPLATE
46	PMRAM-90QH5	S36	1	FRONTPLATE
48	PMRAC-63CA1	S02	1	2P TERMINAL
50	PMRAM-90QH5	S33	5	2 UNION
51	PMRAM-90QH5	S34	3	3 UNION
52	PMRAM-90QH5	S35	2	4 UNION