



NO.	PART NO.	Q'TY / UNIT	PARTS NAME
1	KPNT1 001	6	PUSH NUT
2	PMRAM-33NP2E S04	1	CABINET
3	PMRAC-19SH4 S01	1	THERMISTOR (OUTSIDE TEMPERATURE)
4	PMRAC-25NH4 S14	1	SUPPORT (FAN MOTOR)
5	PMRAM-72Q8 S03	1	THERMISTOR (OH)
6	PMRAC-51CA1 908	1	NET
7	PMRAC-VX13CGT S01	1	TOP COVER
8	PMRAC-63CA1 S02	1	TERMINAL BOARD (2P)
9	PMRAC-SX10CB S04	1	OVERLOAD RELAY COVER
10	PMRAC-VX13CET S02	1	FAN MOTOR
11	PMRAC-VX13CET S04	1	TERMINAL BOARD (3P)
12	PMRAC-VX10CJ S04	1	D-GRILL
13	PMRAC-X10CZ S05	1	PROPELLER FAN
14	PMRAC-X13CX 902	2	VALVE 2S
15	PMRAM-33NP2E S05	1	REACTOR
16	PMRAM-33NP2E S06	1	ELECTRICAL EXPANSION COIL (R)
17	PMRAM-33NP2E S07	1	ELECTRICAL EXPANSION COIL (W)
18	PMRAM-33NP2E S08	2	EXPANSION VALVE
19	PMRAM-33NP2B S06	1	COIL (REVERSING VALVE)
20	PMRAM-33NP2B S07	1	REVERSING VALVE
21	PMRAM-33NP2E S10	1	THERMISTOR-V-N
22	PMRAM-33NP2E S09	1	THERMISTOR-V-W
23	PMRAM-35QH5 S04	1	STRAINER (COND)
24	PMRAM-40NE2F S01	1	P.W.B. (MAIN)
25	PMRAM-40NE2F S02	1	P,W,B (INVERTER)
26	PMRAM-33NP2E S03	1	COMPRESSOR
27	PMRAM-40NP2B S04	1	STRAINER (PIPE)
28	PMRAM-40QH5 905	1	SV COVER
29	PMRAM-40QH5 908	1	STRAINER (COND 1)
30	PMRAM-40QH5 909	1	STRAINER (COND 2)
31	PMRAM-40QH5 913	1	STRAINER (ST-PIPE-AS-1)
32	PMRAM-40QH5 914	1	STRAINER (ST-PIPE-AS-2)
33	PMRAM-40QH5 S03	1	SIDE PLATE (R)
34	PMRAM-40QH5 S10	1	CONDENSER
35	PMRAM-40QH5 S11	1	THERMISTOR (DEFROST)
36	PMRAS-51CHA1 R15	1	THERMISTOR SUPPORT
37	PMSMARTY235M 902	2	VALVE 3S
38	PMRAC-AJ10CLT S06	3	COMPRESSOR RUBBER